

① Derive an equation for amplifier gain in semi-conductor optical amplifier (SOA).

One of the most important parameters of an optical amplifier is the signal gain or amplifier gain  $G$ , which is defined as

$$G = \frac{P_{\text{out}}}{P_{\text{in}}} \rightarrow (1)$$

where  $P_{\text{in}}$  &  $P_{\text{out}}$  are the input & output powers respectively of the optical signal being amplified.

The Signal gain in the active medium is

$$G = \exp [r(g_m - \alpha)L] = \exp [g(z)L] \rightarrow (2)$$

where  $r$  is the optical confinement factor in the cavity,  $g_m$  is the material gain coefficient,  $\alpha$  is the effective absorption coefficient of the material in the optical path,  $L$  is the amplifier length, and  $g(z)$  is the overall gain per unit length.

Eqn (2) shows that the gain increases with device length.

An expression for the gain  $G$  as a function of the input power can be derived by examining the gain parameter  $g(z)$  in eqn (2). This parameter depends on the carrier density and the signal wavelength.  $g(z)$  is given by

$$g(z) = \frac{g_0}{1 + \frac{P_s(z)}{P_{\text{amp. sat}}}} \rightarrow (3)$$

where,

$g_0 \rightarrow$  unsaturated medium gain per unit length in the absence of signal input.

$P_s(z) \rightarrow$  internal signal power at point  $z$ .

$P_{\text{amp, sat}} \rightarrow$  amplifier saturation power.

Given that  $g(z)$  is the gain per unit length in an incremental length  $dz$  the light power increases by  $dP = g(z) P_s(z) dz$

$$dP = g(z) P_s(z) dz \rightarrow (4)$$

Substitute eq<sup>n</sup> (3) into eq<sup>n</sup> (4) and rearranging terms gives

$$g_0(z) dz = \left( \frac{1}{P_s(z)} + \frac{1}{P_{\text{amp, sat}}} \right) dP$$

Integrating their eq<sup>n</sup> from  $z=0$  to  $z=L$  yields

$$\int g_0(z) dz = \int \left( \frac{1}{P_s(z)} + \frac{1}{P_{\text{amp, sat}}} \right) dP$$

Defining the single pass gain in the absence of light to be  $G_0 = \exp(g_0 L)$

and using eq<sup>n</sup> (1), we then have

$$G = 1 + \frac{P_{\text{amp, sat}}}{P_{x,\text{in}}} \ln \left( \frac{G_0}{G} \right)$$

① Discuss the external pumping mechanism used in SOA with necessary mathematical equation.

→ External current injection is the pumping method used to create the population inversion needed for having a gain mechanism in SOA. This is similar to the operation of laser diodes.

$$\frac{dn(t)}{dt} = R_p(t) - R_s(t) - \frac{n(t)}{\tau_r} \rightarrow (1)$$

where,

$$R_p(t) = \frac{J(t)}{qd} \rightarrow (2)$$

i.e. the external pumping rate from the injection current density  $J(t)$  into the active layer of thickness  $d$ ,  $\tau_r$  is the combined time constant coming from spontaneous emission and carrier-recombination mechanism and

$$R_{st}(z) = \Gamma \alpha g (n - n_{th}) N_{ph}$$

$$= \Gamma v_g N_{ph} \rightarrow (3)$$

i.e. the net stimulated emission rate there,  $v_g$  is the group velocity of the incident light.  $\Gamma$  is the optical confinement factor,  $\alpha$  is a gain constant,  $n_{th}$  is the threshold carrier density,  $N_{ph}$  is the photon density and  $g$  is the overall gain per unit length. Given that the active area of the optical amplifier has a width  $w$  and a thickness  $d$ , then for an optical signal of power  $P_s$  with photons of energy  $h\nu$  and group velocity  $v_g$ , the photon density is

$$N_{ph} = \frac{P_s}{v_g(h\nu)(wd)}$$

③ Consideration Edfa being pumped at 980 nm with a 30mW pump power. If the gain at 1550 nm is 20dB. Find (i) the maximum input and output power of the amplifier.

→ Maximum input power is

$$P_{x.in} \leq \left( \frac{980}{1550} \right) (30\text{mW})$$

$$P_{x.in} \leq 19.1\text{mW}$$

Maximum output power is

$$P_{x.out}(\text{max}) = P_{x.in}(\text{max}) + \frac{\lambda_p}{\lambda_x} P_{p.in}$$


$$= 19.1\text{mW} + 0.63 (30\text{mW})$$

$$P_{x.out}(\text{max}) = 19.1\text{mW}$$

$$P_{x.out}(\text{max}) = 12.8\text{dBm}$$

(4) Explain the working of Erbium doped fiber amplifier using Energy level diagram.

→ The most popular material used for telecommunication application is a silica fiber doped with erbium medium in an EDFA. The active medium in an optical fiber amplifier consists of a nominally 10 to 30m length of optical fiber that has been lightly doped with a rare earth element. The operating region of these devices depends on the host material and the doping element.



The Erbium atoms in silica are actual  $\text{Er}^{3+}$  ions, which are erbium atoms that have lost three of their atoms or the transition of the outer  $e^-$  in these ions to higher energy states, it is common to refer to the process as "raising the ion to higher energy levels". The 2 principle levels are at metastable states, the pump, and the ground state levels are actually bands of closely spaced energy levels that form a monogold due to the effect known as Stark splitting. Further each Stark level is broadened by

thermal effect into continuous band.

The metastable band is separated from the bottom of the  $4|1s|2$  ground-state level by an energy gap ranging from about 0.814 eV at the bottom of the metastable band to 0.814 eV at the top. The energy level for Pump Level exists at a 1.27 eV separation from the ground state. The pump band is fairly narrow, so that the pump band wavelength must be equal to within a few nanometers.

The gap between the top of the  $4|1s|2$  level and the bottom of the material metastable band is around 0.775 eV. The pump laser emitting 980 nm photon is used to excite ions from ground. Sat to pump level shown by transition process - 1.

These excited ions decay very quickly from the pump band to the metastable band shown as transition process-2. Within the metastable state, the  $e^-$  of the excited ions tend to populate the lower end of the band. The absorption of a 1480 nm pump photon excites an  $e^-$  from the ground state directly to the lightly populated top of the metastable level.

These  $e^-$  then tend to move down to the more populated lower end of metastable level (transition 4). Some of the  $e^-$  decay back to ground state in the distance of stimulated photon (transition 5).

An absorbed ion raises these ions to the metastable (transition 6). In the stimulated emission process (transition 7) a signal photon triggers an excited ion to drop to ground state.

⑤ Discuss the salient features of semiconductor optical amplifier.



\* 1310 nm, 1400 nm, 1550 nm and 1610 nm wavelength selectable.

\* A high fiber-to-fiber gain of 20 dB

\* up to 16 dBm output

\* 1 MHz with 10 ns pulse width

\* PM Panda fiber input / output

\* Similar to lasers, but with non-reflecting ends and broad wavelength emission

\* Incoming optical signal stimulates emission of light at its own wavelength.

\* The process continues through the cavity to amplify the signal.

\* small size can be integrated

\* high gain ( $> 30$  dB)

\* low dependence of signal polarization (1 dB)

\* Non-linear properties (saturation)

\* high energy consumption per bit

\* phase noise.

\* Semiconductor optical amplifiers are typically

made from group III-V compound semiconductors

such as GaAs / AlGaAs, InP / InGaAs, InP / InGaAsP

and InP / InAlGaAs.

\* operating signal wavelength b/w 850 nm & 1600 nm and generating gain of up to 30 dB

\* SOA has higher noise, lower gain & high nonlinearity with fast transient time.

⑥ Explain three possible configuration of a EDFA.

→ Three possible configuration of a EDFA are Amplifier noise, power conversion efficiency and gain saturation and gain spectrum.

Amplifier noise :-

The dominant noise generated in an optical amplified is amplified Spontaneous Emission, EDFA amplifying a signal at 1540 nm.

The power spectral density of ASE noise is.

$$S_{ASE}(f) = h\nu n_{sp} [g(f) - 1] = P_{ASE} / \Delta v_{opt.} \rightarrow (1)$$

where,  $P_{ASE}$  = ASE noise power in an optical BW.

$\Delta v_{opt.}$  &  $n_{sp}$  = Spontaneous Emission.

Population inversion factor is defined as,

$$n_{sp} = \frac{n_2}{n_2 - n_1} \rightarrow (2)$$

where,  $n_1$  &  $n_2$  are the factorial densities.

From Eq<sup>n</sup> (2),  $n_{sp} \geq 1$ .

With equality holding for an ideal amplifier when the population inversion is complete.

If the total optical field is the sum of the signal field  $E_s$  & the spontaneous emission field  $E_n$ , then the total photodetector current  $i_{tot}$  is proportional to the square of the electric field of the optical signal.

$$i_{tot} \propto (E_s + E_n)^2 = E_s^2 + E_n^2 + 2E_s \cdot E_n.$$

Optical power incident on the photo detector becomes

$$P_o = G P_{s,in} + S_{ASE} \Delta v_{opt.}$$

The total mean-square shot-noise current

$$(i_{shot}^2) = \alpha^2 = \alpha_{shot-S}^2 + \alpha_{shot-ASE}^2$$

$$= 2qRGP_{s,in}B + 2qRS_{ASE} \Delta v_{opt.} B \rightarrow (3)$$

Beat noise of the signal with ASE is

$$\sigma_{S-\text{ASE}}^2 = 4(RGP_{\text{s.in}})(RS_{\text{ASE}}B) \rightarrow (4)$$

$$\sigma_{\text{ASE-ASE}}^2 = R^2 S_{\text{ASE}}^2 (2\Delta V_{\text{opt}} - B)B \rightarrow (5)$$

total mean-square receiver noise current that becomes

$$(i_{\text{total}}^2) = \sigma_{\text{total}}^2 = \sigma_{\text{Z}}^2 + \sigma_{\text{shot-S}}^2 + \sigma_{\text{shot-ASE}}^2 + \sigma_{S-\text{ASE}}^2 + \sigma_{\text{ASE-ASE}}^2 \rightarrow (6)$$

thermal noise variance  $\sigma_e^2$  is given in eqn.

This observation reduces eqn,

$$\sigma_{\text{shot}}^2 = 2qRGP_{\text{s.in}}B. \rightarrow (7)$$

$$\left(\frac{S}{N}\right)_{\text{out}} = \frac{\sigma_{\text{ph}}^2}{\sigma_{\text{total}}^2} = \frac{R^2 G^2 P_{\text{s.in}}^2}{\sigma_{\text{total}}^2} \approx \frac{RP_{\text{s.in}}}{2qB} \frac{G}{1+2\eta n_{\text{sp}}(G-1)} \rightarrow (8)$$

the mean square IP photocurrent is

$$(i_{\text{ph}}^2) = \sigma_{\text{ph}}^2 \approx R^2 G^2 P_{\text{s.in}}^2 \rightarrow (9)$$


Note that the term,

$$\left(\frac{S}{N}\right)_{\text{in}} = \frac{RP_{\text{s.in}}}{2qB} \rightarrow (10)$$

$$\text{Noise figure } F = \frac{(S/N)_{\text{in}}}{(S/N)_{\text{out}}} = \frac{1+2\eta n_{\text{sp}}(G-1)}{G} \rightarrow (11)$$

when  $G$  is large, this becomes  $2\eta n_{\text{sp}}$ .


A perfect amplifier would have  $n_{\text{sp}}=0$ , yielding a noise figure of 2 or 3 dB.



## Gain spectrum

The signal wavelength of the CW laser signal is swept from 1525 nm to 1600 nm, which enables evaluating the spectral gain and the BW of the amplifier.


Gain 1(dB) vs. frequency.



## Gain saturation

The layout of gain saturation enables evaluating the amplifier performance as a function of the signal input power. The amplifier performance given by gain, OLP power & noise figure.

Gain 1(dB) vs. Power.




7) Name the four possible application of optical amplifier and explain each of them with figure.

→

Application of optical amplifier are :-

- \* In-Line optical amplifier
- \* Pre amplifier
- \* Power amplifier.

In-line optical amplifier :-




In a single mode link the effects of fiber dispersion may be small so that the main limitation to repeater spacing is fiber attenuation.

Such a link does not necessarily require a complete regeneration of the signal.

Simple amplification of the optical signal is sufficient the optical amplifier is sufficient the optical amplifier can be used to compensate for transmission loss & increase the distance between regenerative repeater.


Pre amplifier :-



It is used as a front end preamplifier for an optical receiver. A weak optical signal is amplified before

photo detection. so that the SNR degradation caused by thermal noise in the receiver electronic can be suppressed. Compare with other front end amplifiers such as avalanche photodiode or optical heterodyne detectors. It provides a target gain factor & a broaded bandwidth.


### Power amplifier:-



Power amplifier.

Power or booster amplifier application includes placing the device immediately after an optical transmission to boost the transmitted power while serve to increase the transmission distortion by (10-100 km) depending on the amplifier gain & fiber loss.

### LAN booster amplifier:-



Local area network or a booster amplifier to complete for coupler - insertion loss & power splitting loss.

### Applications :-

- \* In-line amplifier to increase transmission distance
- \* Pre amplifier to improve receiver sensitivity
- \* Booster of transmitted power
- \* Booster of signal level in a local area network

(8) Illustrate the power conversion Efficiency & Gain in EDFA.

→ Power Conversion efficiency & Gain :-

The i/p & o/p power of an EDFA can be expressed in terms of the principle of Energy Conservation.

$$P_{x.out} \leq P_{x.in} + \frac{\lambda_p}{\lambda_x} P_{p.in} \rightarrow (1)$$

where,  $P_{p.in}$  = i/p power pump.

$\lambda_p$  &  $\lambda_x$  = pump & signal wavelength.

Thus power conversion Efficiency defined as,

$$PCE = \frac{P_{x.out} - P_{x.in}}{P_{p.in}} \approx \frac{P_{x.out}}{P_{p.in}} \leq \frac{\lambda_p}{\lambda_x} \leq 1 \rightarrow (2)$$

Quantum-efficiency Conversion is defined by,

$$QCE = \frac{\lambda_x}{\lambda_p} PCE \rightarrow (3)$$

If there is no spontaneous emission, then

$$G = \frac{P_{x.out}}{P_{x.in}} \leq 1 + \frac{\lambda_p}{\lambda_x} \frac{P_{p.in}}{P_{x.in}} \rightarrow (4)$$

The input signal power cannot exceed a value given by

$$P_{x.in} \leq \frac{(\lambda_p/\lambda_x) P_{p.in}}{G-1} \rightarrow (5)$$

In this case with any amplifier, as the magnitude of the output signal grows EDFA increase the amplifier gain eventually starts to saturate. the reduction of gain in an EDFA occurs when the population inversion is reduced significantly by a large signal, thereby yielding the typical gain-versus-power performance curve.

- ⑨ Consider an InGaAsP SOA that has cavity dimensions,
- Active area width ( $w$ ) =  $3\text{ }\mu\text{m}$
  - Active area thickness ( $d$ ) =  $0.3\text{ }\mu\text{m}$  and
  - Amplifier length ( $L$ ) =  $500\text{ }\mu\text{m}$

Assume the SOA has a

- Confinement factor ( $\gamma$ ) =  $0.3 \times 10^{-3}$
- Time constant ( $\tau$ ) =  $1\text{ ns}$
- Gain co-efficient ( $a$ ) =  $2 \times 10^{-20}\text{ m}^2$
- Threshold density ( $n_{th}$ ) =  $1 \times 10^{24}\text{ m}^{-3}$

If a  $100\text{ mA}$  bias current is applied to the device, determine the pumping rate & zero signal gain for the SOA

- If a  $100\text{ mA}$  bias current is applied to the device, the pumping rate is

$$(R_p =) \frac{J}{qd} = \frac{I}{qd\omega L}$$

$$= \frac{0.14 \text{ A}}{(1.6 \times 10^{-9} \text{ C})(0.3 \mu\text{m})(3 \mu\text{m})(500 \mu\text{m})}$$

$$R_p = 1.39 \times 10^{33} \text{ (electron/m}^3\text{)/s.}$$

the zero-signal gain is

$$R_0 = 0.3 \left( 2.0 \times 10^{-29} \text{ m}^2 \right) (1\text{ ns}) \left( \frac{1.39 \times 10^{33} \text{ m}^{-3} - 1}{1.0 \times 10^{24} \text{ m}^{-3}} \right)$$

$$R_0 = 2340 \text{ m}^{-1}$$

$$R_0 = 23.4 \text{ cm}^{-1}$$